

Disassembly Instructions For
Height Adjustable Tables

1. Separate top from base by unscrewing the hardware under the top.
2. Remove all visible fasteners.
3. Sort each component according to material.
4. Check with your local recycling center to find out if the materials are recyclable (varies depending on region/country).

Tools

